

# LapCool5

NOTEBOOK COOLER



Rubber Feet      70 mm FANS      Rubber Feet



USB mini-B      USB Hub

## Package Contents

LapCool 5  
USB mini-B Cable  
USB 5V Power Cable

## Using the LapCool 5

Place the LapCool 5 on a stable, flat surface. Place the rear of notebook on the LapCool 5 and position it so that it sits stably.

## Powering the LapCool 5

The LapCool 5 can be powered by either the USB mini-B cable or the USB 5V Power Cable. Connect either cable to the LapCool 5 and then connect the USB-A end to your computer. If the fans do not start spinning, make sure the fan control knob is not in the OFF position.